

## Remote ABCD Tuning– EGA Board



How to tune your E8 remote to the main EGA-04 V2 control board.  
The EGA V2 board is identifiable by the on/off switch on the board.

Before you start, Press the A button, if an orange light appears on your remote  
Please proceed. ( if the orange light is not visible, this is not the correct remote)

**Step 1:** Press and hold the A , the blue light will flash on the board to signal it recognises the remote

**Step 2:** Press the learn button on the controll board once. Do not hold the button.

**Step 3:** Press the A button remote 1.

Please note: the number on the display represents which remote you have tuned.

Repeat step 3 until all your remotes are tuned.

## Delete ABCD remotes – EGA board

**Step 1:** Press and hold the Learn button on the control board  
until you see 00 on the display screen.

**Step 2:** Release the button, all remotes are deleted from the control board